

DAVIS®

DAVIS®

Cloud Chair Series
Designed by Wolfgang C.R. Mezger



Cloud Chair Series Adjustments

Height Adjustment

The right-hand lever (sitting in chair) actuates the gas lift mechanism.

- To **raise** height: Lift the lever while lifting your weight from the chair. The chair will follow your body up. Release the lever and the new height position will be held.
- To **lower** height: Lift the same lever while sitting in the chair. Let the chair move down with your weight and release the lever at the desired height.

Tips regarding height adjustment:

Find the height at which your feet are flat on the floor and the back of your thighs are comfortably supported by the seat cushion. Too much pressure on the back of your thighs means the chair is too high; too little pressure means it is too low.

Forward Position Lock Feature

The position lock is intended to hold the back in an upright position while the user is seated in the chair.

The right-hand lever (sitting in chair) also locks and unlocks the rear tilt mechanism.

- To **engage** the lock, pull lever forward to stop back tilt.
- To **release** the lock, push the lever back for full tilt.

Tips regarding rear tilt lock:

The lever should be moved either completely back to disengage or completely forward to engage the lock.

